

Slide Screen

3 – Attach the housing into the clips, 1st into the inside groove, then “turn” into the lip side & press to snap the housing into place.



4 – On Single doors attach the vertical side profile with the magnet to the opposite side of the door using three screws.

5 – Top & Bottom Rails:

Hinged Doors:

Measure the opening width and deduct the following when cutting the top and bottom rails.

For Single Doors please deduct: **1 3/4” inches**

For Double Doors please deduct: **3 3/8” inches**

Sliding Patio Doors or Other Surface Mounted Applications:

First, determine the best location for mounting the screen housing. This location will vary depending upon the style and brand of door. On sliding glass doors it is most typical to mount the housing so that the rear most end rests approximately 1 1/2” in on the stationary panel center mullion. Next, measure the horizontal opening from the inside edge of the housing (the innermost part of the housing end cap protruding shoulder-see exploded view system 36 drawing), to the inside edge of the side profile where it will eventually rest. Do this both top and bottom as they may vary then cut both the upper and lower guide rails to size and crimp the insect pile in-place.

6 – Single Doors: Next, slide one end of your top and bottom rails onto the protruding shoulder of the screen housing end cap. You may now position to top and bottom rails within the side rail and gently press into place and secure with screws. Using the plastic pile opener will make it easier to see around the insect pile and inside the top or bottom rails while securing the screws.

Double Doors: Next (since there is no side rail on a double door), take the second screen housing and slide rails onto the top and bottom housing end caps protruding shoulders. Now, slide the rails and housing carefully into the opening, position and snap the second housing into mounting clip positions and simply secure the top and bottom rails using screws.



The Top & Bottom Rail Each Have a Decorative Trim Groove On One Side. This Groove Should Always Face the Away From the Door.